



BT2000 Battery Tester Quick Setup Guide

How to Personalize Battery Test Printout:

1. After installing AA batteries, connect battery tester to a 12-volt battery
2. On the menu screen, scroll to and select "Information"
3. Enter up to 4 lines and 16 characters per line of personalized store information, spaces do count as a character (ex. Name of store, phone number, etc.)
4. Once customization is complete, perform a battery test; once test is complete, print receipt to confirm that your selected customized wording at bottom of receipt is correct
5. If customized wording is not correct, please repeat steps 2-4

How to Operate Battery Tester:

Step 1. Connect battery tester to the battery terminals

Step 2. Select type of test you would like to perform "**BATTERY TEST**" (Used on 99% of vehicles), "**START-STOP TEST**" (Used on vehicles such as BMW, Mercedes and Porsche with Start-Stop battery technology) or "**SYSTEM TEST**" and press <<Enter>>

Step 3. Select battery type "EFB/AGM FLAT PLATE" or "**FLOODED**" (most common battery type), AGMF, AGMS, VRLA, GEL and press <<Enter>>

Step 4. Select battery rating "**SAE/CCA**" (most common battery rating), "EN", "IEC", "DIN", (***note SAE & CCA are same**) and press <<Enter>>

Step 5. Input battery capacity (***note SAE & CCA are same**) and press <<Enter>>

Step 6. Confirm the battery location and press <<Enter>>

Step 7. Device will begin testing battery

Step 8. Point tester to battery to receive temperature measurement and press <<Enter>>

Step 9. Tester will display test results for Temperature, SOC (State of Charge), SOH (State of Health) press <<Enter>>

Step 10. Tester will display test code press <<Enter>>

Step 11. Select "YES" or "NO" to print test results press <<Enter>>

Battery Tester Warranty:

12 Month Limited Warranty

Need Replacement Cables?

To order replacement cables part # R201, please contact Legacy Partners Associates at 1-844-294-6280 or sales@lpassoc.com

For further questions regarding your DHC battery tester please contact our customer service department at:

Phone: 1-844-294-6280

Email: service@lpassoc.com

Website / Videos: www.dhctesters.com